



IP Interfaces from BR Remote come pre-configured to operate on a LAN and have our standard XLR3 and XLR4 connectors. They also operate over a VPN using the internet in the same plug-and-play manner. They use standard 12v power supplies. When connecting to a controller the unit is powered from the controller. When connecting to a camera it uses the camera power supply and passes power on to the camera.

- No fiddly power connectors with odd voltage PSUs.
- Standard XLR & RJ45 connectors.

RS485 to IP MultiCaster

Connects to a controller and broadcasts to multiple IP-485 receivers simultaneously.

IP to RS485 Converter

Receives data from a multicaster and connects directly to 1 or multiple cameras.

RS422 / RS485 full Duplex over IP

2 units which connect via TCIP, configured as a full duplex RS485 connection. Each direction is completely independent from the other in all respects. These are used on our multi-camera systems with multiple controllers. Any other RS422/485 data can use these units.

The simplest method of using the units over the internet is to set up a VPN between the control site and the remote site. There is no further configuration needed to the IP Interfaces.